

How to insert and fill a liner in an Arena tote

Below are instructions for proper insertion of a CDF form-fit liner into an Arena tote.



Remove liner from box.



Unfold liner once horizontally and then once vertically. Remove plastic wrap from fitments.



Grab the two back corners so the dispense fitment is towards the front-right of the liner.



Place liner in tote with dispense fitment end in first.



Place four corners of liner into the four corners of the tote.



Hold onto the top of the liner where the filling fitment is located.



Place fill fitment in fill bridge and attach Cam-lock.



Pull dispense fitment through the dispense chamber and guillotine of the tote.



Attach hose and begin filling process.

