

# Winder Assembly

Below are instructions on how to use the winder assembly with a CDF form-fit liner.



Item needed:  
Winder



Tote is ready for dispense.



Place winder on opposite side of  
dispense location.



Tear perforated flap from liner.



Insert perforated flap into winder.



Before dispensing, start winding  
flaps into winder.



As liner dispenses, continue to  
wind liner into winder and move  
toward dispense fitment.



Continue winding pass  
fill fitment.



Liner is fully dispensed.

