

BULLYSM

Column Guard

Excellent choice for racks with non-seismic foot-plates.

Prevents damage to rack columns.

Anchoring options prevent twisting of column when loads are dragged against the upright column.



*Repairs low level damage when welded or bolted to the rack column. Dents disappear and column is reinforced.**


Snug fit around rack column eliminates loose anchor bolts when guard is impacted.

11 ga. sleeve and 6x6x3/8" footplate provide excellent protection.

Available 3" to 48".

Available for racks with standard footplates. Other footplates are optional and must be quoted by the factory.

* Contact your dealer representative before using the column guard for repairing damaged racks.



For information contact: